



JASON-RANHEIM COMPANY

580 Parrott Street
(408) 287-0259

San Jose, California 95112
(408) 287-0264

UPGRADE CAPTURE ROM V1.1

Here is the new ROM we promised. It does the following:

- 1- Permits easy cartridge generation using CPR cartridge kits.
- 2- Eliminates the need to disconnect some printer interfaces while booting CAPTURE® disks.
- 3- Permits loading from tape after preconfiguring RAM.

To install the new ROM in your CAPTURE® cartridge:

- 1- Open your CAPTURE® cartridge case using a wide-bladed screwdriver to assist in prying the two halves apart. Careful!
- 2- Remove the CAPTURE® ROM from its socket. Use a nail file or small screwdriver to pry it out a little at a time from each end.
- 3- Lay the new ROM on its side on a flat surface. With a rotating motion, bend all the 'legs' at once so they are perpendicular to the EPROM body. Repeat for the 'legs' on the other side.
- 4- Insert the new ROM in the socket. To do this, hold CAPTURE® so the gold "fingers" are pointed at you. Hold the ROM so that the notch points to the left. Insert one side of the ROM a very small way into the socket, and then the other side of the ROM. When all the legs are engaged in the socket, push the ROM in to seat it all the way.
- 5- Re-assemble the case.

Notes -

To use CAPTURE'd disks with EPYX FAST LOAD or ACCESS MACH 5, you can type the following prior to loading:

POKE770,131:POKE771,164:POKE816,165:POKE817,244<CR>.

Or you can save a little 'prebooter' on your disk to accomplish the same thing:

10SYS64789:LOAD"BT.<NAME>",8,1