

Addendum for Demo Disk Version 2.3

Some Commodore 64 and 128 computers may have a problem loading the SPEECH EDITOR program on the HEARSAY 1000 DEMO DISK. We think the problem is due to a quirk in the Commodore KERNAL ROM. In an effort to solve this problem we have rewritten the loader portion of the SPEECH EDITOR and renamed it SPEECH EDIT.BAK.

If the SPEECH EDITOR program does not load on your Commodore computer, try loading the backup copy by typing:

LOAD "SPEECH EDIT.BAK",8,1

Also, some computers may not be able to load the DICTIONARY LOADER program on the HEARSAY 1000 DEMO DISK. Usually this can be corrected by loading the alternate file DIC LOADER. To do this type:

LOAD "DIC LOADER",8

After the program has loaded and the READY prompt appears on the screen, type:

RUN

If after trying these solutions you still have problems using these files, please call our technical support department and they will be glad to help you. The department is open on Tuesdays and Thursdays from 4 PM to 6 PM Eastern Time. The number is (718) 232-7266.

INSTRUCTIONS FOR SWIFT LOAD (If you have this option installed)

Swift Load will allow programs to load up to 5 times faster than normal. It is designed for use with the Commodore 64 or 128 (in 64 mode) and the 1541 or 1571 disk drives. The time required to load a program depends on many factors; including booting technique, error checking, etc. Speeds up to 500% of normal loading time are possible with long, single file program loads. The <Q> key from the HEARSAY 1000's MAIN MENU toggles swift load on or off.

To Activate Swift Load

1. Enter the HEARSAY 1000's MAIN MENU by pressing <RESTORE>. The computer will respond by saying "HEARSAY 1000".
2. Press the <Q> key. The computer will respond by saying "SWIFT LOAD IS NOW ON".
3. Exit the HEARSAY 1000's MAIN MENU by pressing <RETURN>.
4. Load your program as you would normally do.

To Deactivate Swift Load

1. Enter the HEARSAY 1000's MAIN MENU by pressing <RESTORE>. The computer will respond by saying "HEARSAY 1000".
2. Press the <Q> key. The computer will respond by saying "SWIFT LOAD IS NOW OFF".
3. Exit the HEARSAY 1000's MAIN MENU by pressing <RETURN>.

Some programs may not load the disk directory with both Swift Load and Screen Echo activated. Any attempt to do so may cause the computer to crash!