





**40/80 COLUMN
SWITCH CABLE
FOR THE C-128**

COMMODORE MONITORS



NON-COMMODORE MONITORS



INSTALLATION OF CABLE

Turn off all equipment, install cable as per instructions at left. With switch on the RGB connector in the 40 column position (to the back), turn on the monitor and the computer. Normal 40 column color screen will be displayed. Move switch on RGB connector to the 80 column position (front) Press and release ESC key, then press the X key to toggle cursor between 40 column and 80 column screens. Refer to page 163 of the C-128 System Guide for more information.

It is not necessary to depress the 40/80 DISPLAY key on keyboard when using this INCA cable.

NOTE: 80 column will be in monochrome only.

WARRANTY

This product is warranted for one year against all manufacturing defects which may arise from normal use. Defective product and original sales receipt should be returned to INCA within one year of purchase for repair or replacement. Products that have been damaged or altered for other than normal use (as described in the instructions) will not be accepted for repair or replacement by INCA. Call INCA for an RA # before returning product.

INCA accepts no responsibility for any and all damage caused to user's computer and the user employs this product at his or her own risk.

Not intended for use with RGB monitors or television sets.

Innovative Computer Accessories
1249 Downing Street
P. O. Box 789
Imperial Beach, CA 92032-0837
(619) 224-1177

Copyright © 1985 by INCA